


# ***OPERATOR'S AND PARTS MANUAL***



## ***SNOWBLOWER BLIZZARD B54 & B64 MODELS***

**SERIAL NO. 2024768 AND UP**

**OM 0277-A  
06/02**



# ***BLIZZARD***

by RAD Technologies Inc.



---

# TABLE OF CONTENT

---

|                                                          |    |
|----------------------------------------------------------|----|
| INTRODUCTION – TO THE PURCHASER .....                    | 3  |
| SAFETY PRECAUTIONS.....                                  | 4  |
| Before Operation .....                                   | 4  |
| Notice.....                                              | 5  |
| The Snowblower .....                                     | 5  |
| Before Operation .....                                   | 5  |
| Snowblower operation .....                               | 6  |
| The Tractor .....                                        | 7  |
| General Information .....                                | 7  |
| Operating the Tractor.....                               | 7  |
| During Operation .....                                   | 7  |
| Maintenance .....                                        | 8  |
| Transporting.....                                        | 8  |
| Storage .....                                            | 8  |
| DECALS .....                                             | 9  |
| ASSEMBLY.....                                            | 10 |
| Snowblower Assembly .....                                | 10 |
| Driveline Installation .....                             | 10 |
| Chute & Manual Rotation.....                             | 10 |
| Snowblower Installation .....                            | 12 |
| Removing the Snowblower from the Tractor .....           | 12 |
| Hydraulic Rotation with Cylinder – 8056 (Optional) ..... | 13 |
| OPERATION .....                                          | 14 |
| General Preparation .....                                | 14 |
| Operating Controls .....                                 | 14 |
| Work and Travel Speed .....                              | 14 |
| Raising and Lowering the Snowblower .....                | 14 |
| Drive Shaft Operation .....                              | 14 |
| Manual Rotation .....                                    | 14 |
| Reduction Chain Tension Adjustment .....                 | 14 |
| Skid Shoe Adjustment .....                               | 14 |
| Manual Deflector Adjustment .....                        | 14 |
| Snow Removal Methods .....                               | 15 |

---

# TABLE OF CONTENT

---

|                                                    |    |
|----------------------------------------------------|----|
| MAINTENANCE .....                                  | 16 |
| Maintenance .....                                  | 16 |
| Storage .....                                      | 16 |
| Driveline.....                                     | 16 |
| Lubrication.....                                   | 16 |
| PARTS .....                                        | 17 |
| Introduction.....                                  | 17 |
| Frame and Related Parts - Blizzard B54 & B64 ..... | 18 |
| Gearbox (663485).....                              | 20 |
| Manual Rotation – Kit 9377.....                    | 21 |
| Hydraulic Rotation by Cylinder – Kit 8056.....     | 22 |
| Driveline (665341).....                            | 23 |
| WARRANTY .....                                     | 24 |
| TORQUE SPECIFICATION TABLE .....                   | 25 |

---

# INTRODUCTION

---

## **TO THE PURCHASER**

All BER-VAC and BLIZZARD products are designed to give safe, dependable service if they are operated and maintained according to instructions. **Read and understand this manual before operation.**

This manual has been prepared to assist the owner and operators in the safe operation and suitable maintenance of the implements. The information was applicable to products at the time of manufacture and does not include modifications made afterwards.

Read and understand this operator's manual before attempting to put an implement into service. Familiarize yourself with the operating instructions and all the safety recommendations contained in this manual and those labeled on the implements and on the tractor. Follow the safety recommendations and make sure that those with whom you work follow them.

*To assist your dealer in handling your needs, please record hereafter the model number and serial number of your implement and tractor. It is also advisable to supply them to your insurance company. It will be helpful in the event that an implement or tractor is lost or stolen.*

## **Illustrations**

The illustrations may not necessarily reproduce the full detail and the exact shape of the parts or depict the actual models, but are intended for reference only

## **Direction Reference**

Right Hand and Left Hand are determined by those seen by the conductor looking at the machine while operating.

MODEL :

---

SERIAL NUMBER :

---

DATE OF PURCHASE :

---

---

# SAFETY PRECAUTIONS

---



## **SAFETY FIRST**

This symbol, the industry's "Safety Alert Symbol", is used throughout this manual and on labels on the machine itself to warn of the possibility of personal injury. Read these instructions carefully. It is essential that you read the instructions and safety regulations before you attempt to assemble or use this unit.



**DANGER :** Indicates an immediately hazardous situation which, if not avoided, will result in death or serious injury.



**WARNING :** Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



**CAUTION :** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

**IMPORTANT :** Indicates that equipment or property damage could result if instructions are not followed.

**NOTE :** Gives helpful information.

All products are designed to give safe, dependable service if they are operated and maintained according to instructions. **Read and understand this manual before operation.** It is the owner's responsibility to be certain anyone operating this product reads this manual., and all other applicable manuals, to become familiar with this equipment and all safety precautions. Failure to do so could result in serious personal injury or equipment damage. If you have any questions, consult your dealer.

## **BEFORE OPERATION**

### **Children**

Tragic accidents can occur if the operator is not alert to the presence of children. Children are generally attracted to machines and the work being done. Never assume children will remain where you last saw them.

1. Keep children out of the operating area and under the watchful eye of another responsible adult.
2. Be alert and turn machine off if children enter the work area.
3. Before and when backing, look behind and look for small children.
4. Never carry children while operating the machine. They may fall off and be seriously injured or interfere with safe operation of the machine.
5. Never allow children to play on the machine or attachment even when turned off.
6. Never allow children to operate the machine even under adult supervision.
7. Use extra care when approaching blind corners, shrubs, trees, or other obstructions that might hide children from sight.

---

## **SAFETY PRECAUTIONS- continued**

---

### **NOTICE**

A safe operator is the best insurance against accidents. All operators, no matter how experienced they may be, should read this Operator's Manual and all other related manuals before attempting to operate an implement. Please read the following section and pay particular attention to all safety recommendations contained in this manual and those labeled on the implements and on the tractor.

### **THE SNOWBLOWER**

#### **Before Operation**

1. Read and understand this operator's manual and tractor operator's manual. Know how to operate all controls and how to stop the unit and disengage the controls quickly.
2. Never wear loose, torn, or bulky clothing around the tractor and implement. It may catch on moving parts or controls, leading to the risk of accident.
3. Before the snow season, thoroughly inspect the area where the equipment is to be used and remove all doormats, sleds, boards and other foreign objects.
4. Disengage clutch and shift into neutral before starting the engine.
5. Do not operate equipment in wintertime without wearing adequate winter garments.
6. Never attempt to make any adjustments while engine is running. Read this manual carefully to acquaint yourself with the equipment as well as the tractor operator's manual. Working with unfamiliar equipment can lead to accidents. Be thoroughly familiar with the controls and proper use of the equipment. Know how to stop the unit and disengage the controls quickly.
7. Keep all shields in place and properly tighten all mounting hardware.
8. Periodically, inspect all moving parts for wear and replace with authorized service parts if an excessive amount of wear is present.
9. Replace all missing, illegible, or damaged safety and warning decals. See list of decals in the operator's manual.
10. Do not modify or alter this equipment or any of its components, or any equipment function without first consulting your dealer.
11. Keep safety decals clean of dirt and grime.

---

## **SAFETY PRECAUTIONS- continued**

---

### **Snowblower Operation**

1. Before leaving the tractor unattended, take all possible precautions. Disengage the PTO, stop the engine and remove the ignition key. Lower the implement to the ground.
2. Before starting the snowblower, remove any ice that has accumulated in the auger/impeller.
3. Watch carefully for foreign objects that could enter the blower while operating.
4. Be sure the clutch switch/lever is in OFF position before starting engine.
5. Do not put hands or feet near rotation parts. Keep clear of discharge opening at all times.
6. Exercise extreme caution when operating on or crossing a gravel drive, walks, or roads. Stay alert for hidden hazards or traffic. Do not carry passengers.
7. Adjust collector housing height to clear gravel or crushed rock surface.
8. Stop the engine, remove the key, and allow the rotating parts to stop before unclogging the collector/impeller housing or chute, and making any repairs, adjustments or inspections. Use only a 36" long piece of wood to unclog blower.
9. If the snowblower starts to vibrate abnormally, stop the engine immediately and check for cause. Excessive vibration is generally a sign of trouble.
10. Do not run the engine indoors except when starting engine and transporting attachment in or out of building. Carbon monoxide gas is colorless, odorless and deadly.
11. Exercise extreme caution when changing direction on slopes. Do not attempt to operate on steep slopes.
12. Never operate snowblower without guards, and other safety protective devices in place.
13. Never operate snowblower near glass enclosures, automobiles, window wells, embankments, etc., without proper adjustment of snow discharge angle.
14. Never operate machine at high transport speeds on a slippery surface.
15. Use extra caution when backing up.
16. Do not direct discharge at bystanders or animals. Ejected objects may cause injury.
17. Disengage power to auger/impeller when transporting or when not in use.
18. Never operate the snowblower without good visibility and lighting.
19. Prolonged exposure to loud noise can cause impairment or loss of hearing. Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable noises

---

## **SAFETY PRECAUTIONS- continued**

---

### **THE TRACTOR**

#### **General Information**

1. Read the operator's manual carefully before using tractor. Lack of operating knowledge can lead to accidents.
2. Do not permit anyone but the operator to ride on the tractor. There is no safe place for extra riders.

#### **Operating the Tractor**

1. Never run the tractor engine in a closed building without adequate ventilation, as the exhaust fumes are very dangerous.
2. Never allow an open flame near the fuel tank or battery.
3. Make sure the shield is installed when using a PTO-driven equipment and always replace the shield if damaged.
4. Always bring the tractor to a complete stop, shut off the engine, lower the implement to the ground and remove the ignition key before leaving the tractor.
5. Never park the tractor on a steep slope.
6. Do not attempt to operate on steep slopes.
7. Use of tire chains for better traction and stability is recommended.
8. Always drive the tractor at speeds compatible with safety, especially when operating over rough ground, crossing ditches, or when turning.
9. Handle fuel with care, as it is highly flammable.
10. Use approved fuel container.
11. Never add fuel to a running engine or a hot engine.
12. Fill fuel tank outdoors with extreme care. Never fill fuel tank indoors. Replace fuel cap securely and wipe up spilled fuel.

13. Never allow anyone to operate the snowblower until they are thoroughly familiar with basic tractor and snowblower operation.

14. Make sure the tractor is counterweighted as recommended by your dealer. Weights provide the necessary balance to prevent tip-over or loss of traction or steering.

15. Always make sure all snowblower components are properly installed and securely fastened BEFORE operation.

#### **During Operation**

1. Do not allow anyone to ride on the tractor/snowblower at any time. There is no safe place for passengers on this equipment. The operator MUST sit in the tractor seat.
2. Eye and hearing protection is recommended when operating the snowblower.
3. Operate only during daylight hours, or when the area is well lit with bright artificial light.
4. Disengage the PTO (turn to "OFF"), place the transmission in neutral, set the parking brake, shut off the engine and remove the key, and make sure rotating components have stopped BEFORE leaving the operator's seat.
5. Inspect the snowblower after striking any foreign object to assure that all snowblower parts are safe and secure and not damaged.

---

## SAFETY PRECAUTIONS- continued

---

### **MAINTENANCE**

Park the tractor/snowblower on level ground, set the parking brake, disengage the PTO, shut off the engine, remove the key, and lower the implement to the ground BEFORE making any snowblower adjustments.

1. To avoid injury, do not adjust, unclog or service the snowblower with the tractor engine running. Making sure rotating components have completely stopped before leaving the operator's seat
2. Keep the tractor/snowblower clean. Snow and ice build-up can lead to malfunction or personal injury from thawing and refreezing in garage.
3. Always wear eye protection when cleaning or servicing the snowblower.
4. Do not work under any part of the tractor or snowblower, unless it is securely supported by safety stands.
5. Make sure all shields and guards are securely in place following all service, cleaning, or repair work.
6. Do not modify or alter this equipment or any of its components or operating functions. If you have questions concerning modifications, consult with your dealer.

### **TRANSPORTING**

1. If the tractor/snowblower is to be driven on public roads, it must be equipped with an SMV (Slow Moving Vehicle) sign. Check local traffic codes that may apply to unit usage on public roads and highways in your area.
2. Be alert for all other traffic when driving the tractor/snowblower on public roads or highways.


### **STORAGE**

Before storing the snowblower, certain precautions should be taken to protect it from deterioration.


1. Clean the snowblower thoroughly.
2. Make all the necessary repairs.
3. Replace all Safety Signs that are damaged, lost, or otherwise become illegible. If a part to be replaced has a sign on it, obtain a new safety sign from your dealer and install it in the same place as on the removed part.
4. Repaint all parts from which paint has worn or peeled.
5. Lubricate the snowblower as instructed under "**Lubrication**" section.
6. When the snowblower is dry, oil all moving parts. Apply oil liberally to all surfaces to protect against rust.
7. Store in a dry place.

# DECALS


**Replace immediately if damaged.**



660989



660988



656779




664459



664467



664458



655834

**Located on driveline**




656780

**Included with Option 8056**



664548



656781

# ASSEMBLY


## SNOWBLOWER ASSEMBLY

The snowblower is assembled at the factory, however, snowblower kit must be assembled. Use the present manual and lay out all parts for assembly. Separate bolts and nuts into various sizes. After assembly, torque all the bolts according to the Torque Specification Table enclosed at the end of the manual.

### Driveline Installation

1. Remove paint from snowblower gearbox drive shaft and grease driveline sliding surfaces and yoke.
2. Remove the bolt of the yoke and slide driveline yoke over drive shaft using sliding action of the driveline. Make sure the driveline is well secured to the drive shaft by replacing the bolt and tightening it according to the torque specification table.


**Figure 1**




### Chute & Manual Rotation

1. Place the anti-friction ring (fig.2, item 4) over the chute base, placing the raised part upside and toward the center of the frame.

**Figure 2**



2. Insert the 1 11/16"lg. plastic bushing (fig.4, item 11) in the worm rotation bracket (fig.4, item 6). Grease the two ends of the rotation worm (fig.4, item 5) and insert the rotation worm in the bushing (fig.4, item 11).
3. Insert the 1 5/16" plastic bushing (fig.4, item 10) in the tube welded behind blower (fig.3, item 1)
4. Install the assembly by placing the worm rotation bracket (fig.4, item 6) under the right upper plate of the snowblower (fig.3, item 2).



**Figure 3**

# ASSEMBLY

5. Install the adjustment tube (fig. 2, item 3) in the lower hole on the backside of the chute and the adjustment rod (fig. 2, item 2) in the upper hole. Lock in place using the 1/4" x 2" (fig. 2, item 7) cotter pins then insert the Ø5mm x 100mm hair pin (fig. 2, item 6) in the adjustment tube hole (fig. 2, item 3)
6. Install the chute (fig.2, item 1) over the plastic insert (fig.2, item 4), applying grease in between, and place the four retaining plates (fig.2, item 5). Secure using eight 1/4" x 3/4" bolts, lockwashers and nuts (fig.2, items 8-9-10). Tighten all bolts securely.
7. Install the support angle (fig 4, item 21) on the 3 point left attaching plate using two 3/8"NC x 1 1/4" bolts, lockwashers and nuts (fig. 4, items 16-17-18). Tighten securely.
8. Install anchor tube (fig.4, item 15) on the support angle (fig.4, item 21) using a 3/4"NC x 1 1/2" bolt, lockwasher and nut (fig. 4, items 22-23-24) making sure the tube leans toward the tractor.
9. Insert handle bracket (fig.4, item 14) inside anchor tube (fig.4, item 15). Adjust the height of the handle bracket according to your needs and shorten it if necessary. Fasten loosely with a 3/8" x 5/16" set screw (fig 4, item 19).
10. Insert assembled rotation tube (fig.4, item 2) inside the rotation worm. Align holes and insert a 10-24 x 1" capscREW (fig.4, item 12) making sure the capscREW sinks in the worm. Secure with a nylon lock nut (fig. 4, item 13).
11. Install the plastic grommet (fig.4, item 20) in the handle support.
12. Insert the handle (fig.4, item 1) inside the grommet and inside the rotation tube (fig.4, item 2). Select desired length, align nearest holes and secure with a 5mm x 100mm hairpin (fig. 4, item 8).
13. Adjust handle position and height to a comfortable and safe operating position after the snowblower has been mounted to the tractor. Tighten setscrew (fig 4, item 19) on anchor tube and the 3/4" x 1 1/2" bolt securely (fig. 4, item 22).




Figure 4

# ASSEMBLY



**CAUTION:** To avoid personal injury, check the full lifting range of the snowblower, to ensure that the chute rotation handle is clear of the operator's area when the snowblower is in raised position.

14. Install plastic handle (fig.4 item 9) over rotation handle.
15. Tighten all bolts according to the Torque Specification Table at the end of the manual.

**NOTE:** To convert to a **HYDRAULIC DEFLECTOR**, replace the adjustment rod and tube with a 2" x 6" cylinder.

## **Snowblower Installation**

1. Attach tractor lower hitch arms (fig.5, items 1) to snowblower attaching plates using the hitch pins and secure with linchpins (fig.5, items 2).
2. Install the tractor upper hitch (fig.5 item 3) on the upper hole of snowblower (fig.5, item 5) attaching plates using tractors pins and linchpins (fig.5, items 4).
3. Adjust snowblower using the tractor upper hitch so that it runs level.
4. Set the tractor anti-sway turnbuckles so the snowblower does not sway.



**CAUTION:** Before connecting snowblower driveline to tractor drive shaft, make sure driveline is not too long in raised, lowered and middle position. If the driveline is too long it must be shortened, to avoid damaged to tractor.


5. Connect driveline to tractor drive P.T.O., make sure that the driveline yoke pin is properly engaged.

## **Removing Snowblower from Tractor:**

1. Set snowblower completely on the ground to release all pressure from the three-point. Set parking brake and turn engine off.
2. Detach upper link by removing linchpin and pin (fig.5, items 4).
3. Disconnect driveline from tractor P.T.O. shaft and set driveline on support chain.
4. Carefully detach lower links (fig. 5, items 1) by removing linchpins (fig.5, items 2) and loosen anti-sway turnbuckles.

**IMPORTANT:** To avoid damage to the snowblower, retorque all bolts after the first 10 hours of operation.

**Figure 5**




# ASSEMBLY

## ***Hydraulic Rotation with Cylinder 8056 (Optional) Figure 6***

1. Place the plastic anti-friction insert (fig.2, item 4) over the chute base, placing the raised part upside and toward the center of the frame.
2. Install the adjustment tube (fig. 2, item 3) in the lower hole on the backside of the chute and the adjustment rod (fig. 2, item 2) in the upper hole. Lock in place using the 1/4" x 2" (fig. 2, item 7) cotter pins then insert the Ø5mm x 100mm hair pin (fig. 2, item 6) in the adjustment tube hole (fig. 2, item 3)
3. Install the chute (fig.2, item 1) over the plastic insert (fig.2, item 4), applying grease in between, and place the four retaining plates (fig.2, item 5). Secure using eight 1/4" x 3/4" bolts, lockwashers and nuts (fig.2, items 8-9-10). Tighten all bolts securely.
4. Install the cylinder bracket (Fig. 6, item 1) through the Ø13/32" hole on the frame by inserting a 3/8" NC x 1" bolt (item 13), then tighten with a flat washer (Ø7/16" hole), a lockwasher and a nut (items 6-7-8).
5. Install the bell crank (item 2) on the frame by sliding a spacer (item 4) under the cylinder bracket, opposite the Ø11/16"hole. Insert a bushing (item 5) in the Ø1 1/8" hole of the bell crank and slide the bell crank between the flat bars of the cylinder bracket. Fasten everything by inserting a 5/8" NC x 3 3/4" bolt (item 12), a lockwasher and a nut (items 16-17).
6. Install the push arm (item 3) by sliding it between the bell crank plates, greasing generously.
7. Insert a 3/8" x 3/4"NC shoulder screw (item 14) under the part and tighten with a Ø3/8" hole flat washer (item 10) and a 5/16"NC stover.nut (item 9), leaving some movement to the push arm.
8. Slide the other push arm end between the flat bars welded on the chute base. Inserting a Ø7/16" hole nylon flat washer (item 15) under the push arm. Fasten everything with a 3/8" x 1" shoulder screw (item 11), a Ø3/8" hole flatwasher (item 10) and a 5/16"NC stover.nut (item 9), leaving some movement to the mechanism.
9. This system works with a 8" hydraulic cylinder extension and a 20 1/4" centre-to-centre pin retracted.

**Figure 6**



---

# OPERATION

---

## **GENERAL PREPARATION**

1. Read the operator's manual carefully before using the tractor and snowblower. Be thoroughly familiar with the controls and proper use of the equipment. Know how to stop the unit and disengage the controls quickly.
2. Make sure the snowblower is clear of snow before engaging the driveline.
3. Make sure the auger and fan operate freely.
4. Check the oil level in the worm gear box and if necessary, add 80W90 SAE gear oil, AGMA 5EP oil or equivalent.
5. Check the two shear bolts, one on the driving shaft, and the one on the PTO, for proper tightness.
6. Adjust so that the snowblower skid shoes run level.
7. Wear adequate winter outer garments while operating equipment.

## **OPERATING CONTROLS**

### **Work and Travel Speed**

Working ground speed will depend on the depth and density of the snow to be cleared. Normally, ground speed will range from 4 to 7 MPH for light, dry snowfalls 3 to 6 inches, and 1 to 3 MPH for heavy, wet or drifted snow. To transport, disengage the drive shaft and raise the snowblower to full transport height.

### **Raising and Lowering the Snowblower**

Move the three point lever on right hand side of seat down or forward to lower, and up or rearward to raise.

### **Drive Shaft Operation**

The mid drive shaft is activated by pulling up the drive shaft lever on left side of seat. Push down to disengage.

### **Manual Rotation (if so equipped)**

Turning the handle clockwise turns the chute in a clockwise direction.



**WARNING:** To avoid personal injury, be sure the tractor engine is off, the drive shaft disengaged, and all movement has stopped before making any adjustments.

### **Reduction Chain Tension Adjustment**

The premature wear of the chain may be caused by tension being too tight. It is therefore important not to tighten chain to its maximum.

- To adjust the tension on the drive chain, loosen the bolt (item 1), securing the idler sprocket to the snowblower housing.
- To tighten the chain, lower the bolt. Leave approximately 1/8" deflection in one span of the chain. Retighten securely the bolt holding the idler sprocket.

### **Skid Shoe Adjustment**


Adjust the skid shoes so that the snowblower runs level and according to the surface conditions so that stones are not thrown with the snow.

Adjust both skid shoes to the same height to keep the cutting edge level and adjust upwards for smooth surfaces.

Loosen skid shoe bolts (item 2) and adjust according to instructions below, and securely tighten bolts:

#### **Clearance between cutting edge and surface:**

- *Level paved surface :* Adjust to 1/16" to 1/8"
- *Uneven or gravel surface:* Adjust to 1/2" to 5/8"



### **Manual Deflector Adjustment**

Set the angle of deflection according to the distance the snow must be thrown. To set the deflector angle, remove the adjusting pipe hair pin and adjust the adjusting rod to the desired deflector angle. Secure with the adjusting pipe hairpin.

---

# OPERATION

---

## SNOW REMOVAL METHODS

When removing snow, do not use the snowblower as a dozer blade to push snow. Let the snowblower work its way through deep drifts. If the speed of your tractor is too fast, the snowblower may become overloaded and clog. For best results, raise the snowblower and remove a top layer of snow. A second pass with the snowblower will remove the remaining snow.

**IMPORTANT :** Use full RPM power when removing wet, sticky snow. Low RPM power will tend to clog the chute.




**WARNING:** Do not use hands or feet to unclog chute. Do not attempt to clear clogged chute of snow while tractor engine is running. If the chute clogs, disengage the drive shaft, shut off the tractor engine, remove the ignition key, wait for all movement to stop, and then clear the snow from the chute.

A definite pattern of operation is required to thoroughly clean the snow area. These patterns will avoid throwing snow in unwanted places as well as eliminating a second removal of snow

### PATTERN 1


#### DISCHARGE SNOW BOTH SIDES



#### DISCHARGE SNOW BOTH SIDES

Where it is possible to throw the snow to the left and right (above), as on a long driveway, it is advantageous to start in the middle. Plow from one end to the other, throwing snow to both sides without changing the direction of the discharge guide

### PATTERN 2



#### DISCHARGE SNOW THIS SIDE ONLY

If the snow can only be thrown to one side of the driveway or sidewalk (above), start on the opposite side. At the end of the first pass, rotate the discharge guide 180 degrees for the return pass. At the end of each succeeding pass, rotate the discharge guide 180 degrees to maintain direction of throw in the same area.

---

# MAINTENANCE

---

## MAINTENANCE

### Storage

1. Check the shear bolts at frequent intervals for proper tightness to be sure the blower is in safe working condition.
2. Never store the tractor with fuel in the fuel tank inside a building where open flame or sparks are present. Allow the engine to cool before storing in any enclosure.
3. Run the snowblower a few minutes after blowing snow to prevent freeze up of the auger and the impeller.




**WARNING:** Provide adequate blocking before working under the snowblower when in the raised position.

### Driveline

**IMPORTANT:** When the snowblower is not used for more than two weeks, perform driveline maintenance and always store it in a dry place, away from bad weather conditions.

### Lubrication

1. **GEAR** : Check the oil level in the worm gear drive every month. If necessary add SAE 80W90 gear oil, AGMA 5EP or equivalent.
2. **REDUCTION CHAIN** : Lubricate with chain saw lubricant every 4 hours of operation and after each use.
3. **DRIVELINE (S)** : Grease each u-joint fitting every 8 hours of operation. Slide drive shaft apart and coat sliding surfaces with grease every 8 hours of operation.
4. **ROTATION SHAFT** : Grease the shaft each 8 hours of operation.



---

# PARTS

---

## **INTRODUCTION**

All parts are illustrated in "exploded views" which show the individual parts in their normal relationship to each other. Reference numbers are used in the illustrations. These numbers correspond to those in the "Reference Number" (REF) column, and are followed by the description and quantity required.

O/L - "Obtain Locally" in the part number column indicates common hardware that is available at your local hardware supply.


All reference to right and left, forward or rearward, are from the operator's seat, facing the steering wheel.

Orders must give the complete description, correct part number, the total amount required, the serial number, the method of shipment and the shipping address.

The manufacturer reserves the rights to change, modify, or eliminate from time to time, for technical or other reasons, certain or all data, specifications, or the product or products themselves, without any liability or obligation.

# PARTS

## FRAME AND RELATED PARTS – BLIZZARD B54 & B64



# PARTS


## FRAME AND RELATED PARTS – BLIZZARD B54 & B64

| REF. | DESCRIPTION                                | QTY. | PART #  |         |
|------|--------------------------------------------|------|---------|---------|
|      |                                            |      | B54     | B64     |
| 1    | Housing                                    | 1    | ---     | ---     |
| 2    | Chute ass'y                                | 1    | 664793  | 664793  |
| 3    | Nylon ring                                 | 1    | 659151  | 659151  |
| 4    | Bolt hex. 1/4" NC x 3/4"                   | 8    | O/L     | O/L     |
| 5    | Retaining plate                            | 4    | 659146  | 659146  |
| 6    | Lockwasher 1/4" dia. hole                  | 8    | O/L     | O/L     |
| 7    | Nut hex. 1/4" NC                           | 8    | O/L     | O/L     |
| 8    | Cotter pin Ø1/4" x 2"                      | 2    | O/L     | O/L     |
| 9    | Bearing 1 1/4" hole                        | 2    | 4300001 | 4300001 |
| 10   | Bolt hex. 1/2"NC x 1 1/2"                  | 8    | O/L     | O/L     |
| 11   | Lockwasher 1/2"                            | 12   | O/L     | O/L     |
| 12   | Nut hex. 1/2" NC                           | 12   | O/L     | O/L     |
| 13   | Auger                                      | 1    | 666259  | 666269  |
| 14   | Fan                                        | 1    | 664400  | 664400  |
| 15   | Key 3/8" x 3/8" x 2 3/4" lg                | 1    | 654174  | 654174  |
| 16   | Bolt hex. 3/8"NC x 1 1/2"                  | 5    | O/L     | O/L     |
| 17   | Lockwasher 3/8" dia. hole                  | 5    | O/L     | O/L     |
| 18   | Flatwasher 7/16" dia. hole                 | 1    | O/L     | O/L     |
| 19   | Idler bushing                              | 1    | 666264  | 666264  |
| 20   | Idler                                      | 1    | 654010  | 654010  |
| 21   | Flatwasher 11/16" dia. hole                | 2    | O/L     | O/L     |
| 22   | Bolt hex. 5/8"NC x 4 1/2"                  | 1    | O/L     | O/L     |
| 23   | Idler                                      | 1    | 666263  | 666263  |
| 24   | Chain #60 x 72 links, incl. connect. link  | 1    | 659143  | 659143  |
| 25   | Fan washer                                 | 1    | 661554  | 661554  |
| 26   | Adjustment tube                            | 1    | 654076  | 654076  |
| 27   | Adjustment rod                             | 1    | 654074  | 654074  |
| 28   | Hairpin Ø5mm x 100mm lg.                   | 1    | O/L     | O/L     |
| 29   | Driveline series 40                        | 1    | 665341  | 665341  |
| 30   | Hitch pin Cat.1                            | 2    | 654196  | 654196  |
| 31   | Bearing 1 1/8" hole with locking collar    | 1    | 4300016 | 4300016 |
| 32   | Lockwasher 5/8"                            | 1    | O/L     | O/L     |
| 33   | Nut hex. 5/8"NC                            | 1    | O/L     | O/L     |
| 34   | Connecting link #60                        | 1    | 654839  | 654839  |
| 35   | Driving shaft                              | 1    | 666256  | 666268  |
| 36   | Shear plate                                | 1    | 666257  | 666257  |
| 37   | Bolt hex. 5/16"NC x 1 3/4" gr.5, incl. nut | 1    | 665547  | 665547  |
| 38   | Gearbox                                    | 1    | 663485  | 663485  |
| 39   | Nut hex. 3/8"NC                            | 8    | O/L     | O/L     |
| 40   | Bolt hex. 3/8"NC x 5"                      | 4    | O/L     | O/L     |
| 41   | Linchpin 7/16" PTD                         | 2    | O/L     | O/L     |
| 42   | Left adjustable skid shoe                  | 1    | 666254  | 666254  |
| 43   | Right adjustable skid shoe                 | 1    | 666255  | 666255  |
| 44   | Carriage bolt 1/2" NC x 1" lg              | 4    | O/L     | O/L     |
| 45   | Carriage bolt 3/8" x 3/4" lg               | 3    | O/L     | O/L     |
| 46   | Serrated flange nut 3/8" NC                | 3    | O/L     | O/L     |
| 47   | Sprocket #60A32                            | 1    | 654167  | 654167  |
| 48   | Self-lubricating bushing                   | 1    | 659834  | 659834  |
| 49   | Flange with grease slot                    | 1    | 4300014 | 4300014 |
| 50   | Flange with tip and grease fitting         | 1    | 4300015 | 4300015 |

# PARTS

## GEARBOX (663485)


| REF. | DESCRIPTION               | QTY. | PART # |
|------|---------------------------|------|--------|
| 1    | Casing                    | 2    | 659848 |
| 2    | Gear                      | 2    | 662236 |
| 3    | Shim                      | 1    | 656649 |
| 4    | Bearing                   | 4    | 656653 |
| 5    | Parallel Key              | 2    | 659850 |
| 6    | Input Shaft               | 1    | 664663 |
| 7    | Oil Seal                  | 3    | 659852 |
| 8    | Output Shaft              | 1    | 659853 |
| 9    | Shim                      | 1    | 659854 |
| 10   | Snap Ring                 | 2    | 656652 |
| 11   | Shim                      | 2    | 659855 |
| 12   | O-Ring                    | 1    | 661144 |
| 13   | Plug                      | 1    | 659847 |
| 14   | Bolt hex. M8 x 55mm – 8.8 | 8    | O/L    |
| 15   | Nut hex. M8, -8           | 8    | O/L    |



# PARTS

## MANUAL ROTATION – KIT 9377


| REF. | DESCRIPTION                       | QTY | PART # |
|------|-----------------------------------|-----|--------|
| 1    | Handle                            | 1   | 658252 |
| 2    | Rotation tube                     | 1   | 660188 |
| 3    | Rotation yoke                     | 1   | 659595 |
| 4    | Universal block                   | 1   | 658193 |
| 5    | Rotation worm                     | 1   | 659161 |
| 6    | Worm rotation bracket             | 1   | 659145 |
| 7    | Roll pin 1/4" x 1 1/4"            | 1   | O/L    |
| 8    | Hairpin 5mm x 100mm               | 1   | 659073 |
| 9    | Plastic handle                    | 1   | 656797 |
| 10   | Plastic bushing 1 5/16"           | 1   | 657335 |
| 11   | Plastic bushing 1 11/16"          | 1   | 657336 |
| 12   | Capscrew 10-24 x 1"               | 1   | O/L    |
| 13   | Nylon insert locknut 10-24        | 1   | O/L    |
| 14   | Handle support bracket            | 1   | 660187 |
| 15   | Anchor tube                       | 1   | 660269 |
| 16   | Bolt hex. 3/8"NC x 1 1/4"         | 2   | O/L    |
| 17   | Nut hex. 3/8"                     | 2   | O/L    |
| 18   | Lockwasher                        | 2   | O/L    |
| 19   | Square head setscrew 3/8" x 5/16" | 1   | O/L    |
| 20   | Plastic grommet                   | 1   | 657390 |
| 21   | Support angle                     | 1   | 660388 |
| 22   | Bolt hex. 3/4"NC x 1 1/2"         | 1   | O/L    |
| 23   | Lockwasher                        | 1   | O/L    |
| 24   | Nut hex. 3/4"                     | 1   | O/L    |



# PARTS

## HYDRAULIC ROTATION BY CYLINDER – KIT 8056


| REF. | DESCRIPTION                              | QTY | PART NUMBER |
|------|------------------------------------------|-----|-------------|
| 1    | Cylinder Bracket                         | 1   | 664450      |
| 2    | Bell Crank                               | 1   | 664451      |
| 3    | Push Arm                                 | 1   | 664452      |
| 4    | Spacer                                   | 1   | 664429      |
| 5    | Bushing                                  | 1   | 664428      |
| 6    | Flatwasher (7/16")                       | 1   | O/L         |
| 7    | Hex. Nut (3/8" NC)                       | 1   | O/L         |
| 8    | Lockwasher (3/8")                        | 1   | O/L         |
| 9    | Stover Nut (5/16" NC)                    | 2   | O/L         |
| 10   | Flat washer (3/8")                       | 2   | O/L         |
| 11   | Shoulder Screw (3/8" x 1", 5/16" NC)     | 1   | 664583      |
| 12   | Hex. Bolt (5/8" NC x 3 3/4")             | 1   | O/L         |
| 13   | Hex. Bolt (3/8" NC x 1")                 | 1   | O/L         |
| 14   | Shoulder screw (3/8" NC x 3/4", 5/16"NC) | 1   | 664576      |
| 15   | Nylon Flat washer (7/16")                | 1   | O/L         |
| 16   | Lockwasher (5/8")                        | 1   | O/L         |
| 17   | Hex. nut (5/8" NC)                       | 1   | O/L         |



# PARTS

## DRIVELINE (665341)

| REF. | DESCRIPTION                          | QTY. | PART NUMBER |
|------|--------------------------------------|------|-------------|
| 1    | Quick disconnect Yoke - Q.L. type    | 1    | 664543      |
| 2    | Universal Joint Kit                  | 2    | 658094      |
| 3    | Outer Yoke                           | 1    | 664544      |
| 4    | Outer Tube                           | 1    | 659107      |
| 5    | Inner Tube                           | 1    | 659105      |
| 6    | Inner Yoke                           | 1    | 664545      |
| 7    | Yoke with Key                        | 1    | 665350      |
| 8    | Shield                               | 1    | 664547      |
| 9    | Bolt 8mm x 1.25mm x 45mm long gr.8.8 | 1    | O/L         |
| 10   | Nut 8mm x 1.0mm                      | 1    | O/L         |



---

## WARRANTY

---



### ***RAD TECHNOLOGIES INC.***

RAD TECHNOLOGIES INC. warrants to the original buyer that the equipment is free from defects in material and workmanship. RAD TECHNOLOGIES INC.'s obligation, under this warranty, will be limited to the repair or replacement of any non-wear part or component, which RAD TECHNOLOGIES INC. finds to be defective within **one year** from the date of original purchase (unless otherwise-specified). The applicable warranty period for commercial or rental use shall be ninety (90) days from the date of purchase

In no event shall RAD TECHNOLOGIES INC. be liable for consequential, special, direct or indirect damages incurred by the buyer/user.

All components not manufactured by RAD TECHNOLOGIES INC. (such as motors, actuators, hydraulic components, tires, ...etc.) are covered by the original manufacturer's warranty in conjunction with RAD TECHNOLOGIES INC.

RAD's obligation under this warranty shall be limited to repairing or replacing, free of charge to the original purchaser, any part that, in RAD's judgment, shall show evidence of such defect, provided the **distributor** returns the part prepaid within thirty (30) days from date of failure.

This warranty shall not be interpreted to render RAD TECHNOLOGIES INC. liable for injuries or damages of any kind or nature to person or property. This warranty does not extend to losses because of delays, or to any expenses or losses incurred for labor, substitute machinery, rental or for any other reason.

Except as set forth above, RAD TECHNOLOGIES INC. shall have no obligation or liability of any kind on account of any of its equipment and shall not be liable for special or consequential damages. RAD TECHNOLOGIES INC. makes no other warranty, expressed or implied, and specifically, RAD TECHNOLOGIES INC. disclaims any implied warranty or merchantability or fitness for a particular purpose. **Some states or provinces do not permit limitations or exclusions of implied warranties or incidental or consequential damages, so the limitations or exclusions in this warranty may not apply.**

This warranty is subject to any existing conditions of supply, which may directly affect our ability to obtain materials or manufacture replacement parts. RAD TECHNOLOGIES INC. reserves the right to make improvements in design or changes in specifications at any time, without incurring any obligation to owners of units previously sold.

No one is authorized to alter, modify or enlarge this warranty nor the exclusions, limitations and reservations.

**2835 Chemin de l'Aéroport, Thetford Mines (Québec) G6G 5R7**

Tél.: (418) 338-4499 Fax: (418) 388-6090

Internet: [www.radinter.com](http://www.radinter.com) [EMAIL: radtech@radinter.com](mailto:radtech@radinter.com)

## TORQUE SPECIFICATION TABLE

### **GENERAL SPECIFICATION TABLE**

Use the following torques when special torques are not given Note: These values apply to fasteners as received from supplier, when dry. These values do not apply if lubricants are used.

| <b>BOLT SIZES (SAE)</b> | <b>TORQUE</b>      |                      |
|-------------------------|--------------------|----------------------|
| <b>INCHES</b>           | <b>Pounds-Foot</b> | <b>Newtons-Meter</b> |
| 1/4                     | 5                  | 7                    |
| 5/16                    | 10                 | 14                   |
| 3/8                     | 20                 | 27                   |
| 7/16                    | 25                 | 41                   |
| 1/2                     | 88                 | 119                  |
| 9/16                    | 121                | 164                  |
| 5/8                     | 165                | 224                  |
| 3/4                     | 297                | 403                  |
| 7/8                     | 440                | 597                  |
| 1                       | 638                | 865                  |
| 1 1/8                   | 840                | 1139                 |
| 1 1/4                   | 1180               | 1600                 |
| 1 3/8                   | 1570               | 2129                 |
| 1 1/2                   | 2070               | 2807                 |

| <b>BOLT SIZES (METRIC)</b> | <b>TORQUE</b>      |                      |
|----------------------------|--------------------|----------------------|
| <b>MILLIMETERS</b>         | <b>Pounds-Foot</b> | <b>Newtons-Meter</b> |
| M6                         | 10                 | 13                   |
| M8                         | 22                 | 30                   |
| M10                        | 40                 | 54                   |
| M12                        | 59                 | 80                   |
| M14                        | 93                 | 126                  |
| M16                        | 130                | 176                  |
| M18                        | 168                | 228                  |
| M20                        | 205                | 278                  |

Manufactured by:



***RAD Technologies Inc.***

2835, Chemin de l'Aéroport

Thetford Mines, Québec, Canada, G6G 5R7

**Tel.: (418) 338-4499 - Fax.: (418) 338-6090**

**E-mail : [radtech@radinter.com](mailto:radtech@radinter.com)**

**Internet : [www.radinter.com](http://www.radinter.com)**

Printed in Canada